



How do I change my FLIR IP camera's video format?

Copyright

© 2017, FLIR Systems, Inc.

All rights reserved worldwide. Names and marks appearing herein are either registered trademarks or trademarks of FLIR Systems and/or its subsidiaries. All other trademarks, trade names or company names referenced herein are used for identification only and are the property of their respective owners.

Document identity

Publ. No.: LX400088
Commit: 39949
Head: 39949
Language: en-US
Modified: 2017-02-01
Formatted: 2017-02-01

Website

<http://www.flir.com>

Customer support

<http://support.flir.com>


Disclaimer

Specifications subject to change without further notice. Models and accessories subject to regional market considerations. License procedures may apply. Products described herein may be subject to US Export Regulations. Please refer to exportquestions@flir.com with any questions.

FLIR IP cameras include a built-in web interface that can be accessed using a web browser.

The following browsers are supported:

- **(Recommended)** Microsoft Internet Explorer® 8.0 or later, 32-bit version (via ActiveX®)
- Mozilla Firefox® 51.0.1 or later, 32-bit version (via Webplugin)


 NOTE
Google Chrome™ is not supported.

To change the camera's video format:

1. Open Internet Explorer® or Mozilla Firefox on a computer in the same network as your FLIR IP camera. Enter the camera's IP address in the address bar in the following format: **http://IP address**.
 - For example: **http://192.168.0.100**
2. A notification appears for installing the required plug-in. Follow the on-screen instructions to install.
3. Enter the camera user name (default: **admin**) and password (default: **admin**) and click **Login**.



4. Upon login, the web interface opens to the Live View. Click the **Setup** tab.
5. Go to **System > General**.
6. Use the drop-down next to **Video Standard** to select the appropriate video format for your region.



7. Click **Save**.