

Package Contents:



NVR



Ethernet Cable



Power Cable



HDMI Cable



Rack Mount Brackets (x2)



Rack Mount Screws (x6)



USB Mouse



Remote Control



Quick Start Guides

Need Help?

Visit us online for up-to-date software and complete instruction manuals




1 Visit flir.com/security/support

2 Search for the model number of your product

3 Click on your product in the search results

4 Click on the **Downloads** tab

Connecting Your System



This system features automatic firmware upgrades for enhanced functionality. **It is required to upgrade your system to the latest firmware version.**

If a firmware upgrade is available:

1. After startup, a notification will appear asking you to upgrade the firmware. Click **OK** to upgrade.
2. The system will download and install the firmware upgrade. Wait for the firmware update to complete. The system may restart during the firmware upgrade process.

DO NOT power off or disconnect the power cable during firmware installation.

For camera compatibility information, visit flir.com/security/support

* Not included / sold separately.

Using the Mouse

1. LEFT-CLICK:

- **During split-screen display mode:** Click an individual channel to view it in full-screen. Click again to return to the split-screen display mode.
- **While navigating menus:** Click to open a menu option.



2. RIGHT-CLICK:

- **During live view:** Right-click anywhere on the screen to open the Quick Menu.
- **Within system menus:** Right-click to exit menus.

Adding Cameras from the LAN

Follow the steps below to add cameras that are not directly connected to the Power over Ethernet (PoE) ports on the back of the NVR.

NOTE: Please visit flir.com/security/support for a list of compatible IP cameras.

1. Connect the camera to a router or switch on the same network as the NVR.
2. Right-click and select **Device Search**. Log in using the admin account (default User Name: **admin**; default Password: **000000**).



3. Click **Device Search**.
4. Check the camera(s) you would like to add.
5. Click **Add**. The Status indicator turns green to show the camera is successfully connected.

NOTE: If the Status indicator is red, click . Update the camera user name, password, ports, and manufacturer as needed.

6. Click **OK** to save changes.


Setting the Date and Time

It is important to set the correct time to ensure accurate time stamps on video recordings.

1. In live view, right-click and click **Main Menu**.
2. Log in using the system user name (default: **admin**) and password (default: **000000**).
- 3.




4. Click **General** and select the **Date&Time** tab.



5. Click **Apply** to save changes.

Using the Quick Menu

Right-click to open the Quick Menu.



Playback and Search

1. From live view, right-click and then click **Search**.
2. Log in using the system user name (default: **admin**) and password (default: **000000**).
3. Use the calendar on the right to select the date to playback.
4. Use the drop-down menus to select the channels you would like to playback. Click the display options () to playback multiple channels simultaneously.
5. Click inside the video bar to select the playback time. Playback starts immediately at the selected time.

